



Fitting Instruction

Article-No. : 127A024
Product : **Clamp Assy Ø28,6mm**
Vehicle-Brand : **Aprilia**
Model (Type) : **Tuono V4 R / APRC (TY) 2011 →**

Important:

Read this instruction manual carefully and mind all warnings and tips. You should do this work only if you're qualified; otherwise we recommend this mounting to be done by a qualified workshop. Improperly mounting of this kit can reduce the driveability of the motorcycle and may be a risk to your health and life. If not otherwise mentioned, the following tightening torques are recommended: M5 = 5Nm/3.7lbf ft, M6 = 10Nm/7.4lbf ft, M8 = 25Nm/18.4lbf ft, M10 = 40Nm/29.5lbf ft.

The tension and unobstructed movement of Bowden-cables, hydraulic hoses and harnesses might change by the handlebar's new offset. Please mind these advices:

1. Make sure, that the handlebar has got sufficient clearance to the fuel tank and all other parts.
2. All lines/cables must have the necessary length.
3. Secure all lines/cables against bending, twisting or squashing.
4. The bending radius of hydraulic hoses has to be above 40mm. Hoses may not twist when suspension is working or fork is moved across the steering angle.
5. If necessary use longer/shorter brake- and clutch-lines, according to the FMVSS 106 standard.

Fitting:

